

PHILIPS

ENGLISH

Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

■General description (Fig. 1)

- A Spray nozzle (specific types only)
- B Filling opening
- © Steam control
- O = no steam
- → = moderate steam
- ♠ = maximum steam
- = Calc-Clean function
- Spray button ¥ (specific types only)
- Steam boost (specific types only)
- Automatic shut-off light (specific types only)
- **6** Temperature light
- Mains cord
- Anti-Calc tablet (specific types only)
- Type plate
- **W** Water tank
- Temperature dial

■lmportant

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

Never immerse the iron in water.

Warning

- Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself shows visible damage, or if the appliance has been dropped or leaks.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- Never leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children)
 with reduced physical, sensory or mental capabilities, or lack of
 experience and knowledge, unless they have been given supervision or
 instruction concerning use of the appliance by a person responsible for
 their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not let the mains cord come into contact with the hot soleplate of the iron.

Caution

- If the appliance has an earthed plug, it must be plugged into an earthed wall socket.
- Check the mains cord regularly for possible damage.
- The soleplate of the iron can become extremely hot and may cause burns if touched.
- When you have finished ironing, when you clean the appliance, when you fill or empty the water tank and also when you leave the iron even for a short while: set the steam control to position O, put the iron on its heel and remove the mains plug from the wall socket.
- Always place and use the iron on a stable, level and horizontal surface.
- Do not put perfume, vinegar, starch, descaling agents, ironing aids or other chemicals in the water tank.
- This appliance is intended for household use only.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

■Before first use■

2

- 1 Remove any sticker or protective foil from the soleplate.
- 2 Let the iron heat up to maximum temperature and pass the iron over a piece of damp cloth for several minutes to remove any residues from the soleplate.

■Preparing for use

Filling the water tank

Never immerse the iron in water.

- 1 Make sure the appliance is unplugged.
- 2 Set the steam control to position O (= no steam) (Fig. 2).
- 3 Tilt the iron backwards.
- 4 Fill the water tank with tap water up to the maximum level. (Fig. 3)

Do not fill the water tank beyond the MAX indication.

Do not put perfume, vinegar, starch, descaling agents, ironing aids or other chemicals in the water tank.

If the tap water in your area is very hard, we advise you to mix it with an equal amount of distilled water or to use distilled water only.

Setting the temperature

- 1 Put the iron on its heel.
- 2 To set the required ironing temperature, turn the temperature dial to the appropriate position (Fig. 4).

Check the laundry care label for the required ironing temperature:

- Synthetic fabrics (e.g. acrylic, viscose, polyamide, polyester)
- Silk
- • Wool
- • Cotton, linen

If you do not know what kind or kinds of fabric an article is made of, determine the right ironing temperature by ironing a part that is not visible when you wear or use the article.

Silk, woollen and synthetic materials; iron the reverse side of the fabric to prevent shiny patches. Avoid using the spray function to prevent stains. Start ironing the articles that require the lowest ironing temperature, such as those made of synthetic fibres.

- 3 Plug in the appliance. If the appliance has an earthed plug, put the mains plug in an earthed wall socket.
- 4 Let the iron heat up until the temperature light first goes out and then goes on again (Fig. 5).

Note: The temperature light goes on from time to time during ironing.

■Using the appliance

Note:The iron may give off some smoke when you use it for the first time.This stops after a short while.

Steam ironing

- 1 Make sure that there is enough water in the water tank.
- 2 Set the recommended ironing temperature (see chapter 'Preparing for use', section 'Setting the temperature').
- 3 After the temperature light has gone out, set the steam control to the appropriate steam position. Make sure that the steam setting you select is suitable for the ironing temperature selected: (Fig. 6)
- ightharpoonup for moderate steam (temperature settings ightharpoonup to ightharpoonup ightharpoonup
- for maximum steam (temperature settings • to MAX)
- The iron starts to produce steam as soon as it reaches the set temperature.

Ironing without steam

- 1 Set the steam control to position O (= no steam).
- 2 Set the recommended ironing temperature (see chapter 'Preparing for use', section 'Setting the temperature').

-Features

Spray function (specific types only)

You can use the spray function to remove stubborn creases at any temperature.

- 1 Make sure that there is enough water in the water tank.
- 2 Press the spray button several times to moisten the article to be ironed (Fig. 7).

Steam boost (specific types only)

A powerful shot of steam helps to remove stubborn creases.

The steam boost function can only be used at temperature settings between • • • and MAX.

1 Press and release the steam boost button (Fig. 8).

Wait a while before you use the button again to avoid spluttering.

Never direct the steam at people.

Vertical steam boost (specific types only)

You can also use the steam boost function when you hold the iron in vertical position. This is useful for removing creases from hanging clothes, curtains etc.

1 Hold the iron in vertical position. Then press and release the steam boost button (Fig. 9)

Never direct the steam at people.

Automatic shut-off (specific types only)

The automatic shut-off function automatically switches off the heating element if the iron has not been moved for a while.

- The auto-off light starts flashing to indicate that the iron has been switched off by the safety shut-off function (Fig. 10).
- In horizontal position, this happens after 30 seconds.
- In vertical position, this happens after 8 minutes.
- 1 To let the iron heat up again, pick it up or move it slightly.
- If the temperature light goes on, wait for it to go out before you start ironing.
- If the temperature light does not go on, the iron is ready for use.

Cleaning and maintenance

After ironing

- 1 Put the iron on its heel.
- 2 Remove the mains plug from the wall socket and let the iron cool down.
- Wipe scale and any other deposits off the soleplate with a damp cloth and a non-abrasive (liquid) cleaner.

To keep the soleplate smooth, avoid hard contact with metal objects.

Never use a scouring pad, vinegar or other chemicals to clean the soleplate.

- 4 Clean the upper part of the appliance with a damp cloth.
- 5 Regularly rinse the water tank with water. Empty the water tank after cleaning.

Double-Active Calc System (specific types only)

The Double-Active Calc System consists of an Anti-Calc tablet inside the water tank combined with the Calc-Clean function.

- The Anti-Calc tablet prevents scale from clogging the steam vents. The tablet is constantly active and does not need replacement (Fig. 11).
- The Calc-Clean function removes the scale particles.

Calc-Clean function

Use the Calc-Clean function once every two weeks. If the water in your area is very hard (i.e. when flakes come out of the soleplate during ironing), use the Calc-Clean function more frequently.

- 1 Set the steam control to position O.
- 2 Set the temperature dial to MAX.
- 3 Fill the water tank to the maximum level.

Do not pour vinegar or other descaling agents into the water tank.

- 4 Plug in the appliance. If the appliance has an earthed plug, put the mains plug in an earthed wall socket.
- 5 Unplug the iron when the temperature light goes out.
- 6 Hold the iron over the sink and set the steam control to the Calc-Clean position •. (Fig. 12)
- 7 Pull the steam control slightly upwards and gently shake the iron until all water in the tank has been used up.
- Steam and boiling water come out of the soleplate. Scale (if any) is flushed out.
- 8 After you have used the Calc-Clean function, press down the steam control while you turn it to position O.

Note: Repeat the Calc-Clean process if the water that comes out of the iron still contains scale particles.

After the Calc-Clean process

- 1 Connect the iron to the mains to let the soleplate dry.
- 2 Unplug the iron when the temperature light goes out.
- 3 Move the iron gently over a piece of used cloth to remove any water stains that may have formed on the soleplate.
- 4 Let the iron cool down before you store it.

Cleaning the steam control needle

- 1 Pull the steam control out of the appliance. (Fig. 13)
- 2 Use vinegar to remove scale, if any, from the needle (Fig. 14).

Do not bend or damage the steam control needle.

- 3 Reinsert the steam control. Place the point of the needle exactly in the centre of the hole and fit the small projection on the side of the needle into the slot (Fig. 15).
- 4 Set the steam control to position O.

Storage

- 1 Unplug the appliance and set the steam control to position O.
- 2 Empty the water tank (Fig. 16).
- 3 Wind the mains cord round the cord storage facility.
- 4 Store the iron on its heel in a safe and dry place (Fig. 17).

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 18).

■Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at **www.philips.com** or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

■ Troubleshooting

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Centre in your country.

information below, contact the Consumer Care Centre in your country.				
Problem	Cause	Solution		
The iron is plugged in but the soleplate is cold.	There is a connection problem.	Check the mains cord, the plug and the wall socket.		
	The temperature dial is set to MIN.	Set the temperature dial to the required temperature.		
The iron does not produce any steam.	There is not enough water in the water tank.	Fill the water tank (see chapter 'Preparing for use').		
	The steam control is set to position O.	Set the steam control to position ⇔ or ⇔ (see chapter 'Using the appliance').		
Water leaks from the soleplate during ironing.	The iron is not hot enough.	Set the temperature dial to a temperature suitable for steam ironing (• • to MAX). Put the iron on its heel and wait until the temperature light goes out before you start ironing.		
The spray function does not work (specific types only)	There is not enough water in the water tank.	Fill the water tank (see chapter 'Preparing for use').		
Flakes and impurities come out of the soleplate during ironing.	You have been using hard water, which has caused scale flakes to develop inside the soleplate.	Use the Calc-Clean function one or more times (see chapter 'Cleaning and maintenance').		

4239.000.6152.4

Problem	Cause	Solution
The automatic shut-off light flashes (specific types only).	The automatic shut-off function has been activated (see chapter 'Features').	Pick up the iron or move it slightly to deactivate the automatic shut-off function. The automatic shut-off light goes out.
Water leaks from the soleplate while the iron cools down or after it has been stored.	You put the iron in horizontal position while there is still water in the water tank.	Empty the water tank and set the steam control to position O before you store the iron (see chapter 'Storage'). Store the iron on its heel.
The steam boost function or vertical steam boost function does not work (specific types only).	You have used the steam boost function or the vertical steam boost function too often within a very short period.	Put the iron in horizontal position and wait a while before you use the steam boost function or vertical steam boost function again.
	The iron is not hot enough.	Set the temperature dial to a temperature suitable for steam ironing (••• to MAX). Put the iron on its heel and wait until the temperature light goes out before you start ironing.

4239.000.6152.4

INDONESIA

■Pendahuluan

Selamat atas pembelian Anda dan selamat datang di Philips! Untuk memanfaatkan sepenuhnya dukungan yang ditawarkan Philips, daftarkan produk Anda di www.philips.com/welcome.

■Gambaran umum (Gbr. 1)■

- A Nozel semprot (hanya tipe tertentu)
- **B** Lubang pengisian
- Kontrol uap
- O = tanpa uap
- △ = uap sedang
- 😂 = uap maksimum
- = fungsi Calc-Clean
- Tombol semprot ¥ (hanya tipe tertentu)
- Semburan uap ♠ (hanya tipe tertentu)
- **6** Lampu mati otomatis (hanya tipe tertentu)
- **G** Lampu suhu
- Kabel listrik
- Tablet Anti-Calc (hanya tipe tertentu)
- Plat jenis
- 🚺 Tangki air
- Putaran suhu

Penting

Bacalah petunjuk pengguna ini secara seksama sebelum Anda menggunakan alat dan simpan untuk referensi di kemudian hari.

Bahava

Jangan sekali-kali merendam setrika di dalam air.

Peringatan

- Periksa apakah tegangan listrik yang tertera pada pelat sesuai dengan tegangan listrik setempat sebelum Anda menghubungkan alat ini.
- Jangan menggunakan alat jika steker, kabel listrik atau alat itu sendiri menunjukkan kerusakan, atau jika alat pernah terjatuh atau bocor.
- Jika kabel listrik rusak, maka harus diganti oleh Philips, pusat servis resmi Philips atau orang yang mempunyai keahlian sejenis agar terhindar dari bahaya.
- Jangan sekali-kali meninggalkan setrika ini tanpa ditunggui ketika sedang dihubungkan dengan listrik.
- Alat ini tidak dimaksudkan untuk digunakan oleh orang (termasuk anakanak) dengan cacat fisik, indera atau kecakapan mental yang kurang, atau kurang pengalaman dan pengetahuan, kecuali jika mereka diberikan pengawasan atau pengarahan mengenai penggunaan alat oleh orang yang bertanggung jawab bagi keselamatan mereka.
- Anak kecil harus diawasi untuk memastikan mereka tidak bermain-main dengan alat ini.
- Jangan sampai kabel listrik mengenai tapak setrika saat sedang panas.

Perhatian

5

- Jika alat dengan steker yang dibumikan, steker ini harus dimasukkan ke stopkontak dinding yang juga telah dibumikan.
- Cek kabel listriknya secara teratur kalau-kalau ada kerusakan.
- Tapak setrika dapat menjadi sangat panas dan menyebabkan luka bakar jika tersentuh.
- Apabila Anda sudah selesai menyetrika, ketika membersihkan alat, mengisi atau mengosongkan tangki airnya dan juga saat Anda meninggalkan setrika meskipun hanya sebentar: setel kontrol uap ke posisi O, letakkan setrika pada tumitnya dan cabut steker listrik dari stopkontak dinding.
- Selalu simpan dan gunakan setrika pada permukaan yang stabil, rata dan pada posisi rebah.
- Jangan memasukkan parfum, cuka, kanji, zat pembersih kerak, bahan pelembut penyetrikaan atau bahan kimia lainnya ke dalam tangki air.
- Alat ini hanya untuk keperluan rumah tangga.

Medan elektromagnet (EMF)

Alat Philips ini mematuhi semua standar yang berkenaan dengan medan elektromagnet (EMF). Jika ditangani dengan benar dan sesuai dengan petunjuk pengguna ini, alat tersebut aman digunakan menurut bukti ilmiah yang kini tersedia.

Sebelum menggunakan alat pertama kali.

- 1 Lepaskan stiker atau foil pelindung dari pelat tapak setrika.
- Panaskan setrika sampai suhu maksimum dan setrikakan pada sehelai kain lembab selama beberapa menit untuk menghilangkan sisa-sisa kotoran dari tapak setrikanya.

■Menyiapkan penggunaan■

Mengisi tangki air.

Jangan sekali-kali merendam setrika di dalam air.

- 1 Pastikan alat sudah dicabut dari stopkontak.
- 2 Setel kontrol uap ke posisi O (=tanpa uap) (Gbr. 2).
- 3 Miringkan setrika ke belakang.
- 4 Isi tangki air dengan air keran yang dingin sampai level maksimal. (Gbr. 3)

Jangan mengisi tangki air melewati tanda batas MAX.

Jangan memasukkan parfum, cuka, kanji, zat pembersih kerak, bahan pelembut penyetrikaan atau bahan kimia lainnya ke dalam tangki air.

Jika air keran di daerah Anda sangat sadah, kami sarankan Anda mencampurnya dengan air suling dalam jumlah yang sama atau gunakan air suling saja.

Menyetel suhu

- 1 Letakkan setrika pada tumitnya..
- 2 Setel suhu penyetrikaan yang diperlukan dengan memutar putaran suhu ke posisi yang sesuai (Gbr. 4).

Periksa label perawatan pakaian untuk mengetahui suhu setrika yang diperlukan:

- Kain sintetis (misalnya akrilik, viskose, poliamide, poliester).
- Sutera
- • Wol
- ●●● Katun, linen

Jika Anda tidak tahu jenis kain atau bahannya terbuat dari apa, tentukan suhu penyetrikaan yang benar dengan cara menyetrika pada bagian yang tak terlihat apabila Anda mengenakannya.

Sutra, bahan seperti wol dan sintetis: balikkan kain saat menyetrikanya guna mencegah bercak-bercak yang mengkilap. Hindari menggunakan fungsi semprot untuk mencegah noda.

Mulai menyetrika bahan yang memerlukan suhu setrika paling rendah, seperti bahan kain serat sintetis.

- 3 Tancapkan steker pada alat. Jika steker telah dibumikan, masukkan steker pada stopkontak dinding yang telah dibumikan.
- 4 Biarkan setrika memanas hingga lampu suhu padam lalu menyala lagi (Gbr. 5).

Catatan: Lampu suhu akan menyala selagi menyetrika.

■Menggunakan alat■

Catatan: Setrika ini mungkin akan mengeluarkan asap untuk pertama kali digunakan. Ini akan berhenti setelah beberapa saat.

Menyetrika dengan uap

- 1 Pastikan bahwa isi tangki air cukup.
- 2 Setel suhu penyetrikaan yang direkomendasikan (lihat bab 'Menyiapkan penggunaan', bagian 'Menyetel suhu').
- 3 Setelah lampu suhu padam, setel kontrol uap ke posisi uap yang sesuai. Pastikan pengaturan uap yang Anda pilih sesuai untuk suhu penyetrikaan yang dipilih: (Gbr. 6)
- untuk uap sedang (setelan suhu ●● sampai ●●●)
- ⇔ untuk uap sedang (setelan suhu ••• sampai MAX)
- Setrika mulai menghasilkan uap segera setelah mencapai suhu yang disetel.

Menyetrika tanpa uap

- 1 Setel kontrol uap ke posisi O (=tanpa uap).
- 2 Setel suhu penyetrikaan yang direkomendasikan (lihat bab 'Menyiapkan penggunaan', bagian 'Menyetel suhu').

■Fitur

Fungsi semprot (hanya tipe tertentu)

Anda dapat menggunakan fungsi semprot untuk menghilangkan kusut yang membandel pada suhu apa pun.

- 1 Pastikan bahwa isi tangki air cukup.
- 2 Tekan tombol semprot beberapa kali untuk melembabkan pakaian yang akan disetrika (Gbr. 7).

Semburan uap (hanya tipe tertentu)

Semburan uap yang kuat membantu menghilangkan kusut atau lipatan setrika yang membandel.

Fungsi semburan uap hanya bekerja pada setelan suhu antara ●●● dan MAX

1 Tekan dan lepaskan tombol semburan uap (Gbr. 8).

Tunggu sebentar sebelum menggunakan tombol lagi untuk menghindarkan percikan.

Jangan sekali-kali mengarahkan uap pada orang lain.

Semburan uap vertikal (hanya tipe tertentu)

Anda juga dapat menggunakan fungsi semburan uap saat Anda memegang setrika pada posisi berdiri. Ini berguna untuk menghilangkan kusut dari baju yang digantung, tirai, dll.

1 Pegang setrika pada posisi berdiri. Kemudian tekan dan lepaskan tombol semburan uap (Gbr. 9).

Jangan sekali-kali mengarahkan uap pada orang lain.

Mati otomatis (hanya tipe tertentu)

Fungsi mati otomatis akan mematikan elemen pemanas jika setrika tidak digerakkan selama beberapa saat.

- Lampu mati otomatis akan berkedip untuk menandakan bahwa setrika sudah dimatikan oleh fungsi pemutus pengaman (Gbr. 10).
- Pada posisi rebah, ini akan terjadi setelah 30 detik kemudian.
- Pada posisi berdiri, ini akan terjadi setelah 8 menit kemudian.
- 1 Untuk membuat setrika memanas lagi, angkat dan gerakkan sedikit.
- Jika lampu suhu menyala, tunggu hingga padam sebelum mulai menyetrika.
- Jika lampu suhu padam, setrika sudah siap digunakan.

■ Membersihkan dan pemeliharaan Setelah penyetrikaan

- 1 Letakkan setrika pada tumitnya..
- 2 Cabut steker listrik dari stopkontak dan biarkan setrika menjadi dingin.
- 3 Seka kerak air dan endapan lain dari tapak alat dengan lap lembab dan pembersih (cairan) non-ampelas.

Agar pelat tapak setrika tetap licin, jangan sampai tapaknya mengenai benda logam. Jangan sekali-kali menggunakan sabut gosok, cuka atau bahan kimia lainnya untuk membersihkan tapak setrika.

- 4 Bersihkan bagian atas setrika dengan kain lembab.
- Secara teratur, cucilah tangki air dengan air. Kosongkan tangki air setelah dibersihkan.

Double-Active Calc System (hanya tipe tertentu)

Sistem Calc Aktif-Ganda terdiri dari tablet Anti-Calc di dalam tangki air dipadukan dengan fungsi Calc-Clean.

- Tablet Anti-Calc mencegah kerak air menyumbat lubang uap. Tablet ini dapat digunakan terus menerus dan tidak perlu diganti (Gbr. 11).
- Fungsi Calc-Clean menghilangkan partikel-partikel kerak.

Fungsi Calc-Clean

Gunakan fungsi 'Calc-Clean' dua minggu sekali. Jika air di daerah Anda sangat sadah (yaitu apabila serpihan-serpihan kotor keluar dari tapak setrika selama menyetrika), gunakan fungsi 'Calc-Clean' lebih sering.

- 1 Setel kontrol uap ke posisi O.
- 2 Setel putaran suhu ke MAX.

6

3 Isi tangki air sampai tingkat maksimum.

Jangan menuangkan cuka atau zat pembersih kerak lainnya ke dalam tangki air.

- 4 Tancapkan steker pada alat. Jika steker telah dibumikan, masukkan steker pada stopkontak dinding yang telah dibumikan.
- 5 Cabut steker setrika setelah lampu suhu padam.
- 6 Pegang setrika di atas bak cuci dan setel kontrol uap ke posisi Calc-Clean •. (Gbr. 12)
- 7 Tarik sedikit kontrol uap ke atas dan perlahan-lahan goyangkan setrika sampai air dalam tangki habis.
- Uap dan air yang mendidih akan keluar dari tapak setrika. Kerak (jika ada) akan dibilas keluar.

8 Setelah menggunakan fungsi Calc-Clean, tekan kontrol uap sambil memutarnya ke posisi O.

Catatan: Ulangi proses Calc-Clean jika air yang keluar dari setrika masih mengandung partikel kerak.

Setelah proses 'Calc-Clean'

- 1 Hubungkan setrika ke listrik agar pelat tapak setrika mengering.
- 2 Cabut steker setrika setelah lampu suhu padam.
- 3 Gerakkan setrika perlahan-lahan di atas selembar kain bekas untuk menghilangkan noda air yang mungkin terbentuk pada tapaknya.
- 4 Dinginkan dulu setrika sebelum Anda menyimpannya.

Membersihkan jarum kontrol uap

- 1 Tarik kontrol uap keluar dari alat. (Gbr. 13)
- 2 Gunakan cuka untuk membersihkan kerak, kalau ada, dari jarum (Gbr. 14).

Jangan sampai jarum kontrol uap bengkok atau rusak.

- 3 Masukkan kembali kontrol uap. Pasang titik jarum persis di tengah lubang dan sesuaikan proyeksi kecil di samping jarum ke dalam celahnya. (Gbr. 15)
- 4 Setel kontrol uap ke posisi O.

Penyimpanan

- 1 Cabut steker alat dan atur kontrol uap ke posisi O.
- 2 Kosongkan tangki air (Gbr. 16).
- 3 Gulung kabel listrik pada tempat penyimpanan kabel.
- 4 Simpanlah setrika dengan posisi berdiri pada tumitnya di tempat yang aman dan kering (Gbr. 17).

Lingkungan

- Jangan membuang alat bersama limbah rumah tangga biasa jika alat sudah tidak bisa dipakai lagi, tetapi serahkan ke tempat pengumpulan barang bekas yang resmi untuk didaur ulang. Dengan melakukan ini, berarti Anda ikut membantu melestarikan lingkungan (Gbr. 18).

Garansi & servis

Jika Anda butuh servis atau informasi atau jika Anda mengalami masalah, kunjungi situs web Philips di **www.philips.com** atau hubungi Pusat Layanan Pelanggan Philips di negara Anda (Anda dapat menemukan nomor teleponnya dalam leaflet garansi internasional). Jika tidak ada Pusat Layanan Pelanggan di negara Anda, kunjungi dealer Philips setempat.

Pemecahan Masalah

Bab ini merangkum masalah-masalah paling umum yang mungkin Anda temui pada alat. Jika Anda tidak mampu mengatasi masalah dengan informasi di bawah, hubungi Pusat Layanan Pelanggan di negara Anda.

Masalah	Penyebab	Solusi
Setrika tersambung ke listrik tetapi tapaknya dingin.	Ada masalah sambungan.	Periksa kabel listrik, steker dan stopkontak dinding.
	Putaran suhu disetel hingga MIN.	Setel tombol suhu ke posisi suhu yang disyaratkan.
Setrika tidak mengeluarkan uap sama sekali.	Air dalam tangki tidak cukup.	lsi tangki air (lihat babʻPersiapan penggunaan').
	Kontrol uap disetel ke posisi O.	Setel kontrol uap ke posisi ム atau 舎 (lihat bab 'Menggunakan alat').
Air bocor dari pelat tapak sewaktu menyetrika.	Setrika kurang panas.	Setel pemutar suhu ke suhu yang sesuai untuk penyetrikaan dengan uap (●● ke MAX). Letakkan setrika pada tumitnya dan tunggu sampai lampu suhu padam sebelum Anda mulai

menyetrika.

4239.000.6152.4

Masalah	Penyebab	Solusi
Fungsi semprot tidak bekerja (hanya tipe tertentu)	Air dalam tangki tidak cukup.	Isi tangki air (lihat bab 'Persiapan penggunaan').
Serpihan dan kotoran keluar dari tapak setrika selama menyetrika.	Anda telah menggunakan air sadah, sehingga menyebabkan serpihan kerak menumpuk di dalam pelat tapak setrika.	Gunakan fungsi Calc-Clean sekali atau beberapa kali (lihat bab 'Pembersihan dan perawatan'').
Lampu mati otomatis berkedip (hanya tipe tertentu).	Fungsi lampu mati otomatis sudah diaktifkan (lihat bab 'Fitur').	Angkat atau gerakkan setrika sedikit untuk menonaktifkan fungsi mati otomatis. Lampu mati otomatis akan padam.
Air merembes dari tapak setrika saat setrika sedang didinginkan atau setelah setrika disimpan.	Anda meletakkan setrika dalam posisi rebah ketika masih ada air di dalam tangki airnya.	Kosongkan tangki air dan setel kontrol uap ke posisi O sebelum Anda menyimpan setrika (lihat bab 'Penyimpanan'). Simpan setrika pada tumitnya.
Fungsi semburan uap atau fungsi semburan uap vertikal tidak bekerja (hanya tipe tertentu).	Anda terlalu sering menggunakan fungsi semburan uap vertikal dalam waktu singkat.	Letakkan setrika dalam posisi rebah dan tunggu sebentar sebelum Anda menggunakan kembali fungsi semburan uap vertikal.
	Setrika kurang panas.	Setel pemutar suhu ke suhu yang sesuai untuk penyetrikaan dengan uap (●●● ke MAX). Letakkan setrika pada tumitnya dan tunggu sampai lampu suhu padam sebelum Anda mulai menyetrika.

7 4239.000.6152.4